



Installation Sheet for **reusing FACTORY Hip Restraints Club Car Precedent 2004 - Mid Year 2011**

Required tools (7/16" socket wrench, drill w/ 5/16" bit, T30 Torx bit (preferred) or 5/32" allen wrench)



1. Remove existing seat bottom cushion from cart and place cushion (plastic side up) on a flat work surface. Remove 2 front brackets and hip restraints (to prevent mangling of the plastic screw heads, a Torx T30 bit is required). Do NOT discard brackets or hip restraints. The screws are discarded.
2. Place new seat bottom cushion (plywood side up) on a CLEAN work surface. Locate the middle insert in each of the hinge groupings. Reinstall the hinge brackets using 2 of the shorter hex head bolts supplied with your replacement cushion.
3. Using scissors cut this template on dotted line.



Paper should be parallel to outside of hip restraint, Center on Existing Holes



4. As shown, use this template as a guide. Drill 2 new 5/16" diameter holes and expand 2 of the existing holes to 5/16" diameter.
5. Install original hip restraint on new seat bottom cushion using supplied hex head bolts and washers. Use shorter bolts in new holes. Use longer bolts in expanded holes.



Inside of Hip Restraint

Template for use with Club Car Precedent 2004 - Mid Year 2011
with **original factory PASSENGER SIDE HIP RESTRAINT** only
(*larger hip restraint)



Inside of Hip Restraint

Template for use with Club Car Precedent 2004 - Mid Year 2011
with **original factory DRIVER SIDE HIP RESTRAINT** only
(*smaller hip restraint)



6. As shown, use this template as a guide. Drill 2 new 5/16" diameter holes and expand 2 of the existing holes to 5/16" diameter.
7. Install original hip restraint on new seat bottom cushion using supplied hex head bolts and washers. Use shorter bolts in new holes. Use longer bolts in expanded holes. Your seat is now cart ready!



Paper should be parallel to outside of hip restraint, Center on Existing Holes

